



FloorSource

# Scuba II Underlayment

## Specifications

<b>Roll Size</b>	100 sq/ft
<b>Thickness</b>	3 mm
<b>Width</b>	47"
<b>Wt/Roll</b>	9 lbs
<b>Color</b>	Black
<b>Moisture Barrier</b>	6 mil
<b>Material</b>	Neoprene, foam, film, tape



## Description:

Scuba is designed and manufactured with a neoprene layer, the same material found in wet suits. Attached to the material is a 6 mil vapor barrier to provide extra moisture protection so that a separate moisture barrier is not required. Scuba II has a taped edge resulting in a continuous moisture barrier when the ends and sides are taped together. As well as being highly moisture resistant, Scuba II offers a softer and quieter walking experience.

## Installation:

Roll out your first roll of underlayment. On your second roll, remove pressure sensitive tape and overlap the plastic, careful not to overlap foam. Press tape into lip to create a continuous moisture barrier. The unfinished-smooth side should be face down, with the film side facing up. To ensure moisture barrier, end seams must be taped.